

## **STORAGE AND MAINTENANCE INSTRUCTIONS**

To preserve the properties of the polymer nanostructure, the following guidelines must be observed:

- Storage: Membranes should be stored in a dry, shaded area. For "wet" membranes, they must be maintained in a conditioning solution with a concentration of 0.5% – 1.5% to prevent biological growth.
- Chemical Cleaning (CIP): The use of cleaning agents within a pH range of 2 to 11 is permitted. The cleaning temperature must not exceed 40°C.
- Initial Start-up: It is recommended to flush the membrane with demineralized water for a period of 20 – 40 minutes before directing the filtrate to the target system.

